



3CX Yealink T54W Guide

Overview	2
Answering and Placing a Call	4
Answering a Call	4
Placing a Call	4
Placing an Internal Call	4
Hold, Transfer and Park	5
Placing a Call on Hold	5
Transfer a Call	5
Blind Transfer	5
Attended Transfer	6
Transferring a Call to voicemail	6
Parking a Call	6
Picking up a call on Park	7
Conferencing	7
Voicemail	8
Initial Voicemail Setup	8
Accessing Voicemail	8
Retrieve Voicemail from a different IP phone	8
Voicemail Options	9




Yealink T54W Guide

Overview

The purpose of this document is to help walk you through the features and functions of your new Yealink T54W Phone.

We're here to help! If you have any questions about the new functionality please reach out to us at support@datacommplus.com.

Yealink T54W Guide



1	LCD Screen	Display menus and information depending on what you are doing at the time.
2	LED Indicator	Indicates phone status and will flash if there is a voicemail waiting
3	Programmable	Access programmed features. Ex: Parking Spots, Extensions
4	Soft Keys	Call functions that will change depending on what you are doing at the time.
5	Dialpad	Dial a call through the Dialpad.
6	Headset	Activates using a headset on a phone call
7	Mute Button	Mute or Unmute the microphone
8	Message Button	Setup your voicemail or retrieve voicemails
9	Hold Button	Put a call on hold or resume a call on hold
10	Redial Button	Redial a prior number dialed
11	Transfer Button	Transfers a live call
12	Speakerphone	Puts a live call on speaker
13	Volume Button	Turn the volume up or down
14	Direction Keys	Use to move through screen display
15	Cancel Button	Cancel an incoming call or action
16	Speaker	Hear call through the speaker when speakerphone button activated
17	Reversible Tab	Holds handset in place when it is in the cradle
18	Hookswitch	Active when the handset is lifted. Disconnects when the handset is in the cradle.


Answering and Placing a Call

Answering a Call

- Lift the handset, press the *Speakerphone* button, or press the Headset button (if enabled).

Placing a Call


- Lift the handset or press the *Speakerphone* button.
- Dial the number, and press the *Call* Soft Key or the # key



- *No prefix is required when placing an outbound call*

Placing an Internal Call


- Dial the extension of the user + # or *Call* Soft Key
 - Example to dial extension 123: **123#**
- OR locate and press the extension number within the programmable keys of the user you wish to reach.
 - All phones have a toggle button that allows you to access additional extensions (programmable buttons). It is located on the right side, last button of the programmable keys. You will generally see a 1, 2, and 3 next to it



Yealink T54W Guide

Hold, Transfer and Park

The Hold and Transfer keys are located in two places, soft key row and assigned buttons.



Placing a Call on Hold

It is best practice to put a call on hold if you do not need to transfer the call to anyone else. If you need to transfer the call to someone else, follow the steps below for either parking a call or transferring a call.

- While on a call, press the *Hold* key in the soft key row or the *Hold* button
- The options within the Soft Key row will change when you put a call on hold. To pick up the call select the *Resume* option within the Soft Key row. You can also select the *Hold* button on the phone itself to resume a call.



Transfer a Call

There are three options for transferring a call:

- Blind Transfer - Transfer a call directly
- Attended Transfer - Introduce a call before it is transferred
- Transfer to Voicemail - Transfer a call directly to voicemail

Blind Transfer

When transferring a call you will need to select the soft *Transfer* key first and also at the end to complete the transfer.

- While on a call, press the *Transfer* key followed by the extension you wish to transfer to and then *Transfer* again.
 - Example: Transferring a call to extension 123

(Transfer)123(Transfer)

- OR Select the *Transfer* key followed by the extension within the Programmable keys area if extensions have been programmed



Attended Transfer

Attended transfer allows you to introduce a call before you transfer the call.

- While on a call, press *Transfer*, the extension and then press the *Call Soft Key* or #. That will connect you with the person you are transferring the call to. Once you introduce the call, press *Transfer* again and the call will go through.
 - Example: Transferring a call to extension 123 after talking with the person first

(Transfer key)123(Call key) = Talk to the person and then select (Transfer key)

Transferring a Call to voicemail


There will be times that the client requests to go directly to someone's voicemail or the person they are trying to reach requests they are transferred directly to their voicemail.

- While on a call, press the *Transfer* key followed by *4 + the extension number and then *Transfer* again.
 - Example: Transferring a call to the voicemail at extension 123

(Transfer)*4123(Transfer)

Parking a Call

Call Parking is a type of Call Holding. When you park a call, you can pick that call up from ANY phone in the system. If a call is put on hold, you can only pick the call up from that phone. The Park key is located within the Programmable Keys.



- While on a live call, press a *Park* key
 - Depending on what has been programmed there could be multiple Park keys
 - An open parking spot will have a green light next to it.
 - A used parking spot will have a red light next to it.
- The call has now been parked
- Communicate the parking spot where the call resides to the recipient.
 - If the call is not picked up within time programmed, you will receive a ringback


- **Do not select a parking spot with a red light because it will merge the currently parked call and the new call together.**
- **If another call is coming in, once you park the call, press New Call to accept the new call**

Picking up a call on Park

- Go to any phone that is on the system and select the *Park* key that the call was parked on.
 - If there is not a Park key, dial the parking spot + # to pick up the call.
 - Example: Pick up a call parked at SP0: 71#
 - Example: Pick up a call parked at SP1: 72#
- Select Answer
- The call has now been picked up

Conferencing

To create a conference call you will use the Soft Keys row.




- While on a call, press the *Conference* key located in the soft keys. This will place your call on hold and prepare you to dial a second call.
 - Place your second call by dialing the phone number followed by the *Call* key. Once the new call is live, press the *Conference* key again. The calls will be merged.
 - Example: Conferencing in the user at 123-123-1234
- Live call (Conference key)(123-123-1234)(Call key) New call is picked up (Conference key)**

The Soft Keys will perform relevant functions such as splitting the calls, leaving the call, etc. once the conference call is live.

Voicemail

Initial Voicemail Setup


You will want to set up your voicemail right away. You should receive a Welcome Email which will contain the PIN number for the first time you access your voicemail.

- Press the *Message* button 
- Enter the PIN that is provided via your welcome email
- Dial 7 to change your PIN number if you so choose
- Dial 8 to record your greeting



Accessing Voicemail

You will be able to see that there is a voicemail waiting for you by the LED light blinking and/or the Message button flashing.

- Select the *Message* button 
- Enter your PIN number followed by #
- You will hear a recording advising you how many voicemails you have waiting
- Press * to play the voicemail
- Once the voicemail has played you will hear the options available on how to delete, save, etc. that voicemail.
- Once completed you can hang up

Retrieve Voicemail from a different IP phone

You can access your voicemail from a different IP phone other than your own.

- Dial 9999 or 999 (depends on the number of characters in each of your extensions)
- Press “#”
- You will be asked to enter your extension number, type in your extension number
- You will then be asked for your voicemail PIN number. Type in your voicemail PIN number then press “#”
- Follow the voice prompts to check or delete your voicemails.

Voicemail Options

Once you are logged into your voicemail dial 9 to reach Options

- Dialing “1” allows you to change your profile status.
- Dialing “3” allows you to dial a number.
- Dialing “4” allows you to delete all read messages.
- Dialing “5” allows you to change your self-identification message.
- Dialing “6” allows you to play mailbox information.
- Dialing “7” allows you to change your voicemail PIN number.
- Dialing “8” allows you to change your greeting message.
- Dialing “9” allows you to restart the voice menu prompts.

If you need further assistance, please reach out to us at support@datacommplus.com. Once we receive your request one of our representatives will get back to you as soon as possible to help you with any of your phone system needs.